WINERY GLYCOL CHILLER SYSTEM DO IT YOURSELF TIPS

By Jim VanderGiessen Jr, Pro Refrigeration Inc.

I am often asked by winery customers what kinds of things they can do themselves to maintain their glycol chiller systems. The following list of items can hopefully help improve some operating efficiencies, help identify issues before they become serious, and help familiarize you with your glycol chiller system.

1) PROPER GLYCOL CONCENTRATION AND TANK LEVEL

Propylene Glycol is in very simple terms a "Food Grade" Antifreeze. To achieve operating temperatures below 45 F, you will need to add propylene glycol to prevent system freeze up. The standard rule is to maintain a Freeze Point 20 to 25 F below your thermostat set point. For example, if your thermostat is set at 25 F, your freeze point should be 5 F or below the lowest ambient temperatures.

The shaded area in the chart below reflects the recommended range for chiller systems operating in the +25 F temperature range.

	Volume			
Weight %	%	Freezing	Freezing	
Propylene	Propylene	Point in	Point in	Degree
Glycol	Glycol	Fahrenheit	Celsius	Brix**
0	0	32	0.0	0
20	19.4	19.2	-7.1	15.4
25	24.4	14.7	-9.6	19
30	29.4	9.2	-12.7	22
31	30.4	7.9	-13.4	22.7
32	31.4	6.6	-14.1	23.6
33	32.4	5.3	-14.8	24.4
34	33.4	3.9	-15.6	25.3
35	34.4	2.4	-16.5	26.1
36	35.4	0.8	-17.3	26.9
37	36.4	-0.8	-18.2	27.5
38	37.4	-2.4	-19.1	28
39	38.4	-4.2	-20.1	28.5
40	39.4	-6	-21.1	29.1
45	44.4	-16.1	-26.7	31.8
50	49.4	-28.3	-33.5	34.7

shaded area represents recommended Glycol Water Percentage

The most simple way to check your glycol concentration is by using a Refractometer. The Refractometer will provide the freeze point in degrees or in brix.

Another way to check the glycol concentration is by utilizing a hydrometer to determine the specific gravity.

30% Volume = 1.0295 SG = freeze point 9.2 F 35% Volume = 1.0330 SG = freeze point 2.4 F 40% Volume = 1.0372 SG = freeze point -6 F



Misco brand Refractometer

Having too much or too strong of a glycol concentration can also have a negative effect on your chiller system by reducing the heat exchange properties. This will force your system to operate at lower evaporator temperatures and reduce your overall system capacity.

The Glycol Tank Level is also critical to proper operation. Many glycol tanks will have external Sightglasses installed or glycol tank level alarms to help monitor this and alert you of glycol leaks in your system.

^{*}Glycol freeze point should be 20 to 25 F. below operating temperature or below coldest winter ambient conditions. Whichever is coldest.

^{**} Degree Brix is a measure of sugar concentration in a fluid and is important in fermentation applications. Although there are no sugars in glycol, it will affect the refractive index of the fluid in a similar fashion.

2) REFRIGERANT PRESSURES AND GLYCOL TEMPERATURE

The glycol temperature is generally the only data people take notice of on a chiller system. Usually, there are a number of other gauges and instruments that can provide valuable data, even if you have no understanding of refrigeration. We recommend a log be maintained where all of the available operating data is recorded. By recording this data on a regular basis you can be alerted to possible issues before they become critical.



Refrigerant Pressure Gauges should be installed on each compressor on your chiller system. If your chiller system was not supplied with these gauges, request they be added by your refrigeration service mechanic.

Before logging the refrigerant pressures, also note the glycol temperature and ambient temperature (on air cooled systems). These pressures will fluctuate based on the glycol temperature and changing ambient conditions.

3) LIQUID LINE SIGHTGLASS

Most winery chiller systems have a Liquid Line Sightglass located somewhere on the Liquid Refrigerant Line that feeds refrigerant to the Glycol/Refrigerant Heat Exchanger. With the compressor running, you should have a clear Sightglass with no bubbles. It is normal to see bubbles during start up, but these should quickly clear up after 60 seconds. If bubbles are present after start up, this can indicate a low refrigerant charge or even possibly a freeze up condition.



Liquid Line Sightglass



Severely fouled air cooled condenser (Provided by Air Solution Company)

4) AIR COOLED CONDENSER

Most Chiller systems utilize Air Cooled Condensers to reject the heat to the atmosphere. When this condenser gets dirty or obstructed, it can significantly effect the operating pressure of the system and greatly reduce the operating efficiency. This can also cause High Head Pressure Alarms that will shut the system

Care must be taken if you attempt to clean these coils yourself. Be very cautious to not bend or damage the fins, this could cause more harm than a fouled condenser. These coils can be cleaned using compressed air.

For severe applications, specially designed intake screens can be installed to minimize and simplify the cleaning process.

These are just a few easy items to check and monitor on not only the chiller system but any refrigeration system on the winery. For additional articles, troubleshooting guides, glycol percentage charts, and much more please visit our website at www.prochiller.com.

Jim VanderGiessen Jr. is CEO and general manager of Pro Refrigeration Inc., Auburn, WA., a 17 Year Company specializing in manufacturing Glycol Chiller System for numerous Food and Beverage Markets.